

SportFlex

Mounting instructions



Select antenna's mounting location

- You should never let anyone but a fully trained service technician install the antenna on your car.
- If you are to replace an antenna already mounted on your car, simply use the existing hole.
- Preferably install the antenna in the centre of the roof, (approx. 15 cm from the roof edge).
- Install the antenna so that the radiator never protrudes over the side of the vehicle.
- To prevent moisture in the hole, make sure that the antenna base sits flush on the sheet metal.
- Make sure there is sufficient space to fit the cable under the selected mounting location.

Installation of antenna

- Remove the textile from the car ceiling close to the mounting place of the antenna.
- Drill a mounting hole $19\pm 0,5$ mm in diameter or a square hole $14,8\pm 0,1$ mm. If square hole is chosen it must be properly aligned with respect to the vehicle's driving direction. If there is an already existing hole adjust it to above mentioned size.
- To protect from moisture and corrosion; apply anticorrosion grease around the hole's edge.
- Place base gasket on the antenna base.
- When installing the base, make sure that the base gasket is evenly seated on the roof's sheet metal.
- Tighten the antenna base from below using the mount nut (Torque max. 5 Nm, min. 3,5 Nm).

- The mounting nut provides ground bonding to the body of the vehicle. Make sure that there is galvanic connection.
- Connect cable A to the radio, cable B to the telephone and cable C to +13.5 V.
- Screw the radiator on to the base.



- A** AM-FM plug
- B** Telephone connector
- C** +13.5 Volt

SMARTEQ™
WIRELESS TELECOM

SMARTEQ Wireless AB
Enebyberg, Sweden
info@smarteq.se
www.smarteq.com

